



SWITCH POSITIONS	
POS. NO.	S1 INPUT SEL. S2 MODE SEL.
1	TAPE HEAD STEREO
2	PHONO MONO
3	TUNER
4	AUX.

105-120 VOLTS
50-60 CYCLES AC

LAST
R75 C28